

# LX200 Manual

## Push Button Dtmf Dialer / Hotline Dtmf Dialer

---

### ***Installation:***

- 1) Disconnect phone from phone line jack and plug it into one of the jacks on the LX200.
- 2) Connect one end of telephone cord included into the LX200 and the other end into the phone line jack.

### ***Programming Steps:***

- 1) To enter programming lift phone off hook press the button on the LX200 down for 6 seconds then release button, and you should hear a beep. Once in program mode you have 5 seconds to start your operation mode programming. If you delay longer than 5 seconds you will hear 2 beeps timeout and the LX200 will exit programming mode.
- 2) You are now ready to program the operation mode. Modes are as follows (1 = Button Activated, 2 = Off Hook and Button Activated).
- 3) To program the operation mode enter programming as described in step (1) then push button 1 time for button activated or 2 times for off hook and button activated after about 1 second you will hear 1 beep telling you the entry was accepted.
- 4) You are now ready to enter the number for the LX200 to dial. Enter programming data as follows:

Button Pushes	Number	Notes
1	DTMF 1	Press button 1 time and wait for single beep.
2	DTMF 2	Press button 2 times and wait for single beep.
3	DTMF 3	Press button 3 times and wait for single beep.
4	DTMF 4	Press button 4 times and wait for single beep.
5	DTMF 5	Press button 5 times and wait for single beep.
6	DTMF 6	Press button 6 times and wait for single beep.
7	DTMF 7	Press button 7 times and wait for single beep.
8	DTMF 8	Press button 8 times and wait for single beep.
9	DTMF 9	Press button 9 times and wait for single beep.
10	DTMF 0	Press button 10 times and wait for single beep.
11	DTMF *	Press button 11 times and wait for single beep.
12	DTMF #	Press button 12 times and wait for single beep.
13	DTMF A	Press button 13 times and wait for single beep.
14	DTMF B	Press button 14 times and wait for single beep.
15	DTMF C	Press button 15 times and wait for single beep.
16	DTMF D	Press button 16 times and wait for single beep.
17	PAUSE	When you program the pause push the button 17 times and wait for a Single beep and then push the button X times for length of times. Each button push (X) = 500ms

---

### **LC200 • Users Manual**

### ***Programming Example:***

- 1) To program 1010321 and make it button only activated you would do the following:
- 2) Lift phone off hook.
- 3) Press and hold button on LX200 for 6 seconds then release. You should then hear a single beep.
- 4) Press button 1 time and listen for single beep. (This sets it up for button press activation)
- 5) Press button 1 time and listen for single beep.
- 6) Press button 10 times and listen for single beep. **\*\*Note\*\* Do not pause more than 900ms between pushes when programming a digit.**
- 7) Press button 1 time and listen for single beep.
- 8) Press button 10 times and listen for single beep.
- 9) Press button 3 times and listen for single beep.
- 10) Press button 2 times and listen for single beep.
- 11) Press button 1 times and listen for single beep.
- 12) Wait up to 8 seconds for double beep then hang up telephone.
- 13) Program finished.

### ***Operation Modes:***

- ❖ Button Activated - Pressing the button on the LX200 will dial preprogrammed number
- ❖ Button and Off Hook Activated - The LX200 will dial preprogrammed number when the phone is lifted off hook or when the user presses the button.

### ***Setting Dialer Default:***

- ❖ Hold button down and lift the phone off hook, continue to hold the button down for 10 seconds and then release, you should here a single tone for 3 to 4 seconds telling you the command was accepted.

